

### Questions?


### Call Customer Service **1.888.213.5015** Mon-Fri 8am-6pm EST


Visit us online for product support, guides and videos
www.leonspeakers.com/support





#### HzMMB-UT : Horizon Ultra-Thin MatchMount Bracket

Leon's Horizon Ultra-Thin MatchMount Bracket can be used to mount your Leon Horizon speaker directly to the wall, above or below any TV. This versatile bracket offers multiple points of adjustment for a perfect fit, every time.










### **Bracket Hardware**


\*Not to scale

Horizon 👝 Ultra-Thin MatchMount Bracket : HzMMB-UT



\*Not to scale

For assistance, call: 1.888.213.5015 | Mon-Fri 8am-6pm EST



# Mount **TV** level to wall and draw **Guide Line** level with TV edge\*


#### \***Top** or **Bottom** dependent on speaker position 2 people suggested for TV mounting



# Align **Template** level with TV edge\* or **Guide Line** and secure to wall

Template can be secured with masking tape (not provided)





#### Place **Brackets** in **Template** and mark **Pilot Holes\***

\*Mark holes towards top of Bracket



- 8 -




#### Remove **Brackets** and drill\* **Pilot Holes** at mark locations


\*3/32" bit for Wood Screws \*5/16" bit for Drywall Anchors



#### Attach Bracket to wall using Bonded Washers with Wood Screws or Drywall Anchors




- 10 -




## Measure depth from face of TV to the Wall and adjust speaker **Mounting Bolts** to match

Mounting Bolts come pre-installed




# Remove Template and hang speaker by securing **Top Mounting Bolts** in **Brackets**

Top Mounting Bolts come pre-installed



#### Adjust **Mounting Bolts** to align Speaker flush with TV


**Bottom Mounting Bolts** can adjust speaker tilt Front of speaker aligned with front of TV



Side View


### Adjust Lock Nuts to secure assembly

#### Lock Nuts come pre-installed



### Tighten all **Screws** & **Connections** and connect **Wiring** to **Speaker**

\*Ensure flush TV/Speaker alignment before tightening \*You can adjust vertical alignment by sliding the mounting plates





715 W. Ellsworth Road Ann Arbor, Michigan 48108 | 1.888.213.5015 | www.leonspeakers.com

