



Sony Art Frame Gallery App Installation

USER GUIDE



Picture perfect sound.®

To add personal pictures via USB Drive, please refer to step 9 on page 11.

NOTE: Your Studio Frame will conceal your IR receiver. If you intend to use the Sony remote control, refer to the TV manual to enable the bluetooth remote connection. Additionally, you will need to add a simple remote IR extender in order to enable Power ON/OFF.

For CI Dealer assistance, please visit:
<https://www.sonypremiumhome.com/find-a-rep/index.php>
To find your local Sony CI Representative

OVERVIEW


Find detailed Instructions on the following pages.

1. Click the **Settings** button on the top right corner of your Sony remote controller
2. Under settings, scroll down to **APPS**
3. Under **APPS**, scroll to **Security & Restrictions** and select.
4. Within **Security & Restrictions**, enable **CI Tools** under the Unknown Apps bar.
5. Accessing the back of the display, insert the provided USB memory stick that comes preloaded with the SONY Art Frame Gallery app into the upper right USB port.
6. To launch your custom install dashboard from the homescreen, on your remote tap **INPUT** -> tap **MUTE** -> then press and hold **MUTE**
7. From the install dashboard, scroll down to **INSTALL APK** and select it.
8. After selecting **INSTALL APK**, a dialog will appear prompting you to install **ART FRAME GALLERY**.
9. Proceed with the installation by pressing **INSTALL**.
10. Complete install and press **DONE**.
11. Enable simple IP Control by selecting **SETTINGS**. From here, select **Network & Internet**, then scroll down and select **HOME NETWORK**. You will see an option for **IP Control**. Select this, then select to toggle on **Enable Simple IP Control**. A Prompt will tell you that this option may increase power consumption more than the normal configuration. Select **OK**.
12. Reboot your TV by holding down the power button on the remote, then select **Restart**.
13. Launch Art Frame Gallery App from Home menu. Select **Allow** at the prompt, "Allow Art Frame Gallery to access photos, media, and files on your devices?" Art Frame Gallery will begin the process of importing additional images.
14. After import is completed and the contents of the gallery are displayed, remove provided USB memory stick
15. Launch the Art Frame Gallery app from the home screen. Once open, select the settings icon. From here, you can check sensor level (light sensor threshold).
16. Set threshold level below light sensor level. If the motion sensor is enabled, the motion sensor will detect movement according to the set time out range to turn the app on or off.
17. For more detailed instructions regarding the Art Frame Gallery App, please continue on to the following pages of the manual. To add personal pictures via USB Drive, please refer to step 7 on page 10.


App Installation Instructions

1. Enable “Install Unknown Apps”


a.) Enable Install Unknown Apps by selecting **Settings** -> **Apps** -> **Security and Restrictions**.



b.) Navigate to **Unknown Sources** and Press **ENTER**.




c.) Go over to **CI Tool** and press **ENTER** to enable it.




App Installation Instructions

2. Insert Provided USB Memory Stick into the USB Port in the Back of Your TV.



3. Launch CI Tool App


a.) Press the following keys on your Sony TV remote:
tap INPUT -> tap MUTE -> hold MUTE until Custom Install Dashboard Opens.




App Installation Instructions

4. APK Install


a.) Select **INSTALL APK**.



b.) Select the appropriate file name to install the app from the USB.




c.) Select **INSTALL** on the dialogue box.




App Installation Instructions

d.) Wait for the installation to complete.



e.) When installation is complete, select **DONE**.




Move to the next page to Enable Simple IP Control




App Installation Instructions

6. Enable Simple IP Control


a.) Select **SETTINGS**



b.) Navigate down to **Network & Internet** and press **ENTER**.




c.) Scroll down to **Home Network** and press **ENTER**.




App Installation Instructions


d.) Navigate down to **IP control** and press **ENTER**.



e.) Scroll down to **Simple IP control** and press **ENTER**.




f.) Press **OK** on the dialogue box, then reboot your display.




App Installation Instructions

7. Import Art


a.) Launch the Art Frame Gallery App from the Home menu.



b.) A prompt will ask "Allow Art Frame Gallery to Access photos, media, and files on your devices?" Select **Allow**.



c.) The Art Frame Gallery will begin importing additional images.




App Installation Instructions

8. Remove USB Memory Stick


- a.) After image import is complete, remove provided memory stick. **Your app installation is now complete.**

9. Add Your Own Artwork

- a.) Looking to add your own artwork? Load your artwork onto a USB drive (it must be a JPG, located in the root folder of the drive).
- b.) Insert your USB into the back of the display.




- C.) You will see your artwork in the Gallery row labeled “USB” within the Sony Art Frame Gallery App.




App Installation Instructions


- d.) Be sure to add your artwork to the Playlist by selecting the image, and choosing **Add** from the menu that pops up. For best results, images should be formatted to a 16 x 9 aspect ratio.



- e.) A popup will say "Item added to the list".




- f.) You will then see your artwork added to the Playlist.




App Installation Instructions

10. App Settings


- a.) App settings can be changed by selecting the wrench icon in the top right corner of the gallery page.



- b.) We recommend setting the light sensor threshold below the light sensor level and setting the motion sensor time to 30 minutes. (The light sensor supersedes the motion sensor functionality.)



- c.) Matte color and size can also be changed in the app settings.



This page is intentionally left blank

Dealer Notes:

This page is intentionally left blank

Dealer Notes:



715 W. Ellsworth Road Ann Arbor, Michigan 48108 | 1.888.213.5015 | www.leonspeakers.com

Picture perfect sound.®